


Technical report on the mapping of the magnetic field for the NPDGamma experiment at FNPB at the Spallation Neutron Source, ORNL

Jasmin Schaedler, Septimiu Balascuta, Stefan Baessler

Oak Ridge, 08/20/2010

updated in February 2011



Contents

1. The electrical connection of the guide coils:	4
2. How to turn on the power supplies.....	5
2.1 How to turn on the guide coils.	5
2.2. How to turn on the compensation coils:	7
3. Remote control of Power supplies	9
4. Measuring the magnetic field with the flux gate sensors:	9
5. Accuracy of measurements.	13

1. The electrical connection of the guide coils:

There are four horizontal guide coils in the **NPDGamma** experiment. There are a total of $36 + 2 + 1 = 39$ main windings in the bottom and top guide coils and $21 - 2 - 1 = 18$ main windings in each of the two middle coils. In addition there are 12 auxiliary windings laid over each of the four main windings. The main coils are connected in series to the main power supply **DANFYSIK** (Figure 2). The auxiliary coils are connected to the **BK Precision** power supply (Figure 3). The inter-connection between the coils is presented in figure 1.




Figure 1: Guide coil inter-connection

2. How to turn on the power supplies.

The guide coils and the compensation coils are operated by two different power supplies. The two power supplies are presented in figures 2 and 3.



Figure 2: DANFYSIK power supply



Figure 3: BK Precision power supply

2.1 How to turn on the guide coils.

The DANFYSIK power supply requires water cooling; therefore the first action is to turn on the water cooler. This is done by switching the orange power button of the later to **I** (Figure 4). You can check the water level either on the instrument seen on the right side of Figure 4), or by looking into the water inlet at the top of the cooler, or by just looking at the water flow meter shown in Figure 4 right that is installed in the water line.



Figure 4: water cooler (left) and water flow meter (right)

Ideally the DANFYSIK is turned on after the cooler has been running for a few minutes. Then the black switch on the back of the power supply can be pressed (Figure 5). After this has been done, the main power button at the front has to be pressed (Figure 6) to actually turn on the main power supply. After the polarity has been set to **(+)** the big wheel on the left of the front panel can be used to adjust the set-point. Three different settings for the changing speed of the current are available: **coarse**, **medium** and **fine**. Increasing the set-point requires some patience because the power supply needs time to adjust to the new setting. The display shows the current setting and the **ready** light flashes green as soon as the increasing can be continued (Figure 7).

The ideal set-point has been found to be 920000 for a design magnetic field of 9.4 Gauss. For this set-point the output current is 23 A. This setting will be optimized once the spin flipper is used.




Figure 5: Black switch at back of DANFYSIK



Figure 6: Main power button DANFYSIK




Figure 7: change of setpoint

The next step is to turn on the BK Precision power supply. This is done by setting the power switch to I and pressing the output button inwards (Figure 8). To set the power supply to current mode the voltage has to be increased to the maximum followed by a current decrease until the red light in the current display (CC) lights up. Now the current can be set.

The ideal current setting has been found to be 3.3A. The lower limit of the “Fine” tuning knob for which the current is still 3.3 A has to be chosen.

The resistance of the coils changes with the time because they start to heat up. Set the voltage limit to a very high number, it is important to keep the power supply in current mode so that the current stays constant.

The accuracy of the BK Precision is very limited but good enough for the experiment; a change in the BK Precision current of 0.1A can be tolerated but should be avoided.




Figure 8: BK Precision power supply

2.2. How to turn on the compensation coils:

Additionally to the guide coils compensation coils have to be used since the magnetic field is distorted by several factors like the shielding or the polarizer compensation magnets.



Figure 9: The coil stand in the cave; parts of the back and the right shim coil system are marked red.

There are four shim coil systems, one in the back (downstream, close to the Beam Stop, $n=37$), one in the front (upstream, $n=37$), one to the left (beam left, $n=28$) and one to the right (beam right, $n=28$).

They are located on the outer side of the coil stand. Figure 9 is trying to give an idea of the shim coil positions.

The compensation coils are operated by two Agilent power supplies with two outputs each. Agilent 2 (F218734) provides power for the right shim coil system on output [1] and for the front shim coil system on output [2]. Agilent 3 (F218735) provides power for the left shim coil system on output [1] and for the back shim coil system on output [2].

Again it is important to set the power supplies to current mode. The appendix contains an extract of the Agilent user manual where this is explained in great detail (Appendix I).

The currents in the shim coils for which the B field is along the direction of the gravity in the center of the LH2 target:

Left shim: -0.21 ± 0.05 A

Back shim: -0.35 ± 0.05 A

Right shim: -0.5 ± 0.05 A

Front shim: $+0.7 \pm 0.001$ A




Figure 10: Agilent power supplies

To determine the sign of the displayed current the output plugs have to be checked (Figure 10).

Red connected to +: positive current

Red connected to -: negative current

3. Remote control of Power supplies

The Danfysik power supply and the Agilent can also be controlled through the PC. There are separate reports on the wiki how this can be done. The control programs (The VI's) are on the COMPAQ-PC that also performs the magnetic field readout. The BK precision power supply cannot be remotely controlled.

To enable power supply settings, or to readout the magnetic field, the user has to login first. Usually, the "labuser" account should be used (with the password fpiAy2__ - note the two underscore-signs at the end). The administrator account is called myadmin and has the password npdgRoot__, but as usually, shouldn't be used unless necessary.

On the desktop, the user finds the folder NPDG_Remote. It contains the files"

- ag2.vi: This labview program controls the Agilent power supplies. See the separate report.
- df2.vi: This labview program controls the Danfysik power supply. See the separate report.
- fg2new.vi: This labview program reads the fluxgates. See next chapter.

4. Measuring the magnetic field with the flux gate sensors:

First the DAQ Module has to be turned on: this is done by moving the little lever to **On** (Figure 11).



Figure 11: DAQ Module for flux gate sensors

To display the measurements the LabView program has to be started on the computer. The user has to open the folder **NPDG_Remote** located on the desktop and then click the LabView program **fg2new.vi**. After the program has been opened the LabView run button (white arrow) has to be pressed, followed by the green button that says **click to run driver**. After a few seconds the sign "NOT SIGNED ON" will change to "SIGNED ON" and the blue button **click here to start scanning** has to be clicked to start the data acquisition (Figure 12). LabView displays the data for two flux gate sensors. Flux gate 557 is sensor one and flux gate 654 is sensor two, this order should not be changed.




Figure 12: LabView program window

To stop a data run the blue button has to be pressed again followed by the red “Close” button. The collected data can be found on hard drive (C:) in the folder **data**. Every time a new run is started a new text file is created and named with date and starting time. To export the data to another computer, a LAN connection has to be established. This is the only available option because there is no wireless reception in the cave and the USB port of the computer does not work. If the user inserts a memory stick in any USB port will determine the “Windows” operating system to shut down and to try to reboot from the memory drive that was inserted in the USB port.

Positioning of the flux gate sensors:

Since we know the distance from between the guide coil centre and the beam guide flange (98.05”/ 249.05cm), this distance is marked on the coil frame with yellow tape and is used as reference point.

Another important distance is the beam height. Due to the heavy beam stop the steel plates on the floor are not perfectly leveled (relative to the direction of the gravity) and therefore the floor should not be used as reference. Instead the centre of the polarizer which lies on the beam can be found (Figure 13). With the help of a laser the beam height can be transferred from the polarizer to the left wall (Figure 14). Now it is possible to measure the height of the flux gates relative to the beam level without measuring the distance to the floor. This is done by placing a laser at flux gate height pointing towards the left wall where the beam height is marked.




Figure 13: Position of beam marked on polarizer



Figure 14: Laser sitting on stand and indicating height.

Although there are two flux gate sensors available and both measuring stands are designed to support both sensors it is not necessary to use them both at the same time.

Fluxgate 654 has two little feet which sometimes make it difficult to level it relative to the surface of the Aluminum table (Figure 15) when the feet are in contact with this surface and the screws are pressing from the top of the flux gate.



Figure 15: Flux gate 654.

Choice of stand for setup:

Depending on the orientation and direction of the measurement the stand is chosen.

For the gradient measurement the **plate stand** is the better choice since it can be leveled more accurately. There are adjustment possibilities in three different spots and two little bubble levels are attached on top of the stand.




Figure 16: Plate stand with one sensor inside

Remark: The leveling has to be checked after each change in position since the iron floor in the cave is not perfectly flat.

The **rail stand** is used for all the horizontal measurements because it can be easily attached to one of the long rectangular extrusion rails (Figure 17).




Figure 17: Rail stand attached to extrusion rail.

Although this setup is convenient for horizontal changes, vertical changes are a little bit more difficult. To change the height supports of the wished height have to be shimmed at both ends. In Figure 17 this was done with extrusion rails and to control the leveling of the rail the wood wedges were pushed in between. The leveling is indicated by the bubble level located on the bottom wall of

the Aluminum case with two compartments where both the two sensors can be fixed simultaneously with plastic screws.

5. Accuracy of measurements.

All the distance measurements are done with the Leica DISTO D330i distance laser (Appendix II), a caliper or a measuring tape.

Laser accuracy: $\pm 1\text{mm}$

Measuring tape accuracy: $\pm 1/6''/\pm 1.6\text{mm}$

Caliper accuracy: $\pm 1\text{mm}$

The leveling is done with bubble levels.

Leveling accuracy: $\pm 0.02^\circ / 0.00035\text{rad}$

Appendix III contains calibration certificates for both flux gates:

Flux gate sensors accuracy:

The misalignment of the three sensors for the Flux gate 654 (MAG2) are

X 1: 0.0022 radians

Y 1: 0.0034 radians

Z 1: 0.003 radians

The misalignment for the three sensors inside the Fluxgate 557 (MAG1):

X 2: 0.00096 radians

Y 2: 0.0023 radians

Z 2: 0.00025 radians

The offset of the sensors are the fields read by the three sensors when the probe is placed in **zero** magnetic field. The offset fields are given in the calibration certificate for both fluxgates :

Fluxgate 557 : $X1=+3.5\text{ nT}$, $Y1=-10.5\text{ nT}$, $Z1=-3.5\text{ nT}$

Fluxgate 654 : $X2=-6.5\text{ nT}$, $Y2=0$, $Z2=-10.5\text{ nT}$

Appendix I

Chapter 3 Front-Panel Operation and Features Constant Current Operation

Constant Current Operation

To set up the power supply for constant current (CC) operation, proceed as follows.

- **Front-panel operation:**

- 1 Connect a load to the output terminals.**

With power-off, connect a load to the (+) and (-) output terminals.

- 2 Turn on the power supply.**

The power supply will go into the *power-on / reset* state; the output is disabled (the **OFF** annunciator turns on); its low voltage range is selected (annunciator for the range presently selected turns on, for example, the **8V** annunciator turns on for the E3640A model); and the knob is selected for *voltage* control.

Press **High** to operate the power supply in the high voltage range before proceeding to the next step. The **20V** or **60V** annunciator turns on depending on which power supply you are using.

- 3 Set the display to the limit mode.**

Notice that the **Limit** annunciator flashes, indicating that the display is in the *limit* mode. When the display is in the *limit* mode, you can see the voltage and current limit values of the selected supply.

In constant current mode, the current values between the meter mode and limit mode are the same, but the voltage values are not. Moreover, if the display is in the meter mode, you cannot see the change of voltage limit value when adjusting the knob. We recommend that you should set the display to "limit" mode to see the change of voltage limit value in the constant current mode whenever adjusting the knob.

- 4 Adjust the knob for the desired voltage limit.**

Check that the **Limit** annunciator still flashes and the knob is selected for *voltage* control. The flashing digit can be changed using the resolution keys and the flashing digit can be adjusted by turning the knob. Adjust the knob for the desired voltage limit.

¹You can use the resolution selection keys to move the flashing digit to the right or left when setting the voltage.



5 Adjust the knob for the desired output current.

Check that the **Limit** annunciator still flashes. Set the knob for *current* control. Change the flashing digit using the resolution selection keys and adjust the knob to the desired output current.

6 Return to the meter mode.

Press **Display Limit** or let the display time-out after several seconds to return to the meter mode. Notice that the **Limit** annunciator turns off and the display shows "OUTPUT OFF" message.

7 Enable the output.

The **OFF** annunciator turns off and the **CC** annunciator turns on. Notice that the display is in the *meter* mode.

8 Verify that the power supply is in the constant current mode.

If you operate the power supply in the constant current (CC) mode, verify that the **CC** annunciator is lit. If the **CV** annunciator is lit, choose a higher voltage limit.

Note

During actual CC operation, if a load change causes the voltage limit to be exceeded, the power supply will automatically crossover to constant voltage mode at the preset voltage limit and the output current will drop proportionately.

• Remote interface operation:

VOLTage {<voltage> MIN MAX}	Set the voltage
CURRent {<current> MIN MAX}	Set the current
OUTPut ON	Enable the output

¹You can use the resolution selection keys to move the flashing digit to the right or left when setting the current.